

# RESOURCES



**THE PARTY IS OVER!** Here are a few tips to ensure a smooth return. If our team is picking up your rentals, please make sure all items are in one central area.

## PATIO HEATER LIGHTING INSTRUCTIONS

1. Turn the propane cylinder valve open.
2. Press & turn the control knob to High/maximum position.
3. Continue holding down the control knob, press the igniter button several times until the main flame is ignited.  
Release the control knob (30) seconds after ignition.
4. Turn the control knob to Low/minimum for (5) minutes or more before adjusting the knob to the desired temperature setting.
5. If the burner flame goes out, turn off the heater and wait at least 5 minutes or more to let the gas dissipate before re-lighting.

## IMPORTANT INFORMATION

This heater is NOT designed, approved or intended for indoor use or enclosed areas such as a garage, commercial buildings, tents, prefabricated buildings or enclosures. The heater is also NOT designed for use on moving objects or vehicles such as boats, travel trailers, or other moving devices or vehicles.

The patio heater MUST stay in an upright position. It is your responsibility to keep the heater upright and out of weather conditions that could cause the heater to fall/tip over.

It is recommended that there be three feet above the unit and two feet on each side of the unit for clearance.  
Should the heater return damaged/ broken the replacement cost will be assessed on the final invoice

